












# Stairparts Identification Codes

1	BOX NEWEL		18	GOOSENECK 2 RISE NO CAP		35	IRON BALUSTER	
2	BALL TOP NEWEL 5" SQUARE		19	OVER EASING 60°		36	LANDING TREAD	
3	BALL TOP NEWEL 10" SQUARE (RAKE TO LEVEL)		20	TANDEM CAP		37	DOUBLE RETURN TREAD	
4	BALL TOP NEWEL 13" SQUARE (RAKE TO RAKE)		21	LEVEL QUARTERTURN W/CAP		38	DOUBLE BULL NOSE TREAD + RISER	
5	VOLUTE PIN TOP NEWEL		22	STARTING EASING		39	RIGHT HAND RETURN TREAD	
6	TURNOUT PIN TOP NEWEL		23	S-TURN		40	TREAD-NO RETURNS	
7	1/2 NEWEL (BOX)		24	SKIRTBOARD BUTTRESS TYPE		41	SHOERAIL	
8	PIN TOP NEWEL		25	FASCIA		42	RAIL PLOWED WITH FILLET	
9	GOOSENECK 2 RISE WITH TANDEM CAP		26	MITERED SKIRTBOARD		43	RAIL	
10	LEFT HAND VOLUTE		27	RISER		44	SKIRTBOARD BASE CAP	
11	RIGHT HAND TURNOUT		28	WALL SKIRTBOARD		45	COVE MOULDING	
12	RETURNED END		29	SQUARE TOP & BOTTOM TURNED BALUSTER		46	SHOE MOULDING	
13	GOOSENECK 2 RISE RIGHT HAND WITH CAP		30	SQUARE BALUSTER		47	STRINGER BRACKET	
14	GOOSENECK 2 RISE LEFT HAND NO CAP		31	PIN-TOP BALUSTER		48	HAND RAIL BRACKET	
15	ONE OPENING NEWEL CAP		32	IRON SHOE-NEWEL POST		49	ROUND ROSETTE	
16	UP EASING 60°		33	IRON NEWEL POST		50	OVAL ROSETTE	
17	LEVEL QUARTER TURN NO CAP		34	IRON SHOE-BALUSTER				

# Stairparts Configurations

